

Cream- and Ointment Mixer Type POM-5



UAM Motor Drive and Cream- & Ointment Mixer POM-5

Planetary Mixer POM-5

The Planetary Ointment Mixer POM-5 is directly attached to the UAM Motor Drive. It is used for mixing of ointments, crèmes, suspensions, wetted powders and liquids. It consist of a stainless steel (316) mixing kettle, a mixing paddle and a Teflon scraper which is shaped in such a matter that there is a minimum clearance to the mixing kettle. The Kettle can easily be removed from the Planetary Mixer.

The working capacity of the Mixer is approximately 3 litre, depending on the product. The powerful mixer is designed to perform in a reasonably short mixing time a homogeneous product.

Technical Data

Working Capacity: Approx. 3 litre

We reserve the right to make technical changes without any prior notice

40-01170_POM5_1.09E

Page 1